VOLKSWAGEN GROUP

Fleet Interface Policies: Platform Comparison

Platform	Policy	Primary User		Anonymous Driver		Grouping	Additional information
		PU	Mode	GeoData	HMI editable		
MOD4	17	Yes	Leaving	Yes	Yes	Yes	Leaving mode only applies for the anonymous driver. An anonymous driver in a MOD4 vehicle with no Primary User enrolled can switch Privacy Mode on in the HMI, and the vehicle returns to sending vehicle data after each trip.
	18	Yes	Leaving	No	Yes	Yes	
	12	No	Leaving	Yes	No	Yes	Anonymous driver can not turn on privacy settings.
	13	No	Leaving	No	No	Yes	
MOD5	25	Yes	Leaving	Yes	No	Yes	Primary user can not turn on privacy settings neither the anonymous driver.
	26	Yes	Leaving	No	No	Yes	
	12	No	Leaving	Yes	No	Yes	Anonymous driver can not turn on privacy settings.
	13	No	Leaving	No	No	Yes	
FVA	1	Yes	Last Mode	Yes	Yes	Yes	Primary user & anonymous driver can turn on privacy settings. Vehicle always stay to this setting as long as it is not changed.
	4	No	Last Mode	Yes	No	Yes	The anonymous driver cannot change privacy settings. The vehicle retains the last privacy setting until it changes.
MOD3 (after 07.07.2025)	1	Yes	-	-	-	Yes	GeoData always available.
	2	No	-	-	-	-	GeoData always available.
MOD3 (before 07.07.2025)	N/A	Yes	-	-	-	No	No grouping solution available. GeoData always available.

- *Individual agreements* can be set up, if needed or requested by customers.
- Leaving Mode: Vehicle automatically returns to its default settings when exiting. Further description in the column “additional information”.
- Last Mode: Vehicle always automatically returns to it´s most recent settings (e.g. primary user enrolled before ignition off, also activates primary user enrollment after the next ignition on). See also description in the column “additional information”.
- When HMI editable “off”, “leaving” or “last mode” not relevant.